



Performance Bunker Liner Installation

Tools Needed: 50' Flexible Tape Measure, 4' Drywall Square, Utility Knife, Knife Blades, Heavy Duty Scissors (Klien Tools titanium coated high leverage professional shears), 5' 1x6 to use as a cutting board, Construction Adhesive (Loctite PL3), Caulk gun, rubber mallet.

Step 1. Begin preparing the bunker by thoroughly raking and compacting the sub-surface until it is smooth, even, and pitched towards the drainage ditches.

Step 2. Fill all drainage trenches so the stone is level with the sub-surface.

Step 3. Measure and cut Performance Bunker Liner allowing enough for 2 inches extra on both sides to run up the bunker edge. **TIP:** For easier cuts and to keep the liner cuts square use a 4' drywall square and slide a piece of wood underneath to cut on.

Step 4. Continue to cover the entire bunker floor butting the seams together.

Step 5. Cut and trim Performance Bunker liner leaving 2 inches along the edge. (I like to use scissors here so I'm not cutting the liner against the bunker edge and damaging it.)

Step 6. Secure the seams with sod staples. The staples should straddle the seam (one side in each panel) and be secured with a bead of glue to prevent heaving in frost and thaw cycles.

Step 7. Once seams are secure with sod staples, Run a bead of construction adhesive (Loctite PL3) or equivalent. Then take a small putty knife over the bead of glue to spread it out to approximately a half inch.

Finish the installation by sodding the edges and allowing the sod to fall over the liner along the inside edge of the bunker

QUESTIONS:

Call: 717-471-0752

Email: performancebunkerliner@gmail.com

